

This board

Search Networking Knowledge Base - What are you looking for?

Create a new article

Cisco Community > Technology and Support > Networking > Networking Knowledge Base > Reading and Understanding the OSPF Database

[Bookmark](#) | [Subscribe](#) | [Options](#)

202081 36 323

## Reading and Understanding the OSPF Database



plumbis Level 7

04-03-2013 02:59 AM - edited  
03-01-2019 04:54 PM

# Introduction

OSPF, being a link-state protocol, allows for every router in the network to know of every link and OSPF speaker in the entire network. From this picture each router independently runs the Shortest Path First (SPF) algorithm to determine the best path through the network. All of this information is stored in the "Link State Database" (LSDB). Every network engineer has seen the LSDB at some point by running `show ip ospf database` but few actually know how to read the details. By looking only at the LSDB we should have enough information to draw a topology diagram from scratch.

# Link State Advertisements

OSPF uses "Link State Advertisements" (LSAs) to provide information about links and link-costs to neighboring OSPF speakers. OSPF defines multiple LSAs, which all serve a different purpose.

LSA Type	Who Generates the LSA?	What is Accomplished?
Type 1 - Router LSA	Every router in every area	How routers advertise their connected interfaces
Type 2 - Network LSA	DRs on all <b>non</b> -point-to-point links	The DR collects all the Type 1 LSAs and sends out a single Type 2 representing all of the routers on the link. This is used to build the Shortest Path Tree
Type 3 - Network Summary LSA	Area Border Routers (ABRs)	ABRs send a single LSA representing all of the Type 1 and Type 2 LSAs in an area. This reduces the number of LSAs on the routers in other areas.
Type 4 - ASBR Summary LSA	ABRs connected to an area where external routes (Type 5) are originated	Type 4 LSAs are sent to other areas to build the Shortest Path Tree to an ASBR.
Type 5 - AS External LSA	Routers with the <code>redistribute</code> command that are <b>not</b> in a NSSA area	This represents any external routes redistributed into OSPF.
Type 7 - NSSA External LSA	Routers with the <code>redistribute</code> command that <b>are</b> in a NSSA area	Type 5 LSAs are not allowed in Stub Areas. Type 7 LSAs allow external information to pass through NSSA areas.

# Building the Topology

Starting on a router named **r120** we can get a high level overview of the network (or at least our Area).

### Getting Started

Find answers to your questions by entering keywords or phrases in the Search bar above. New here? Use these resources to familiarize yourself with the community:

[How to use Community](#)

[New Community Member Guide](#)

### Quick Links

[Discussions](#)

[Guided Resources](#)

### Related community topics

[ospf multizone understanding](#)

Rowlands Sharles  
11-07-2024 03:46 AM

[Understanding OSPF Cost](#)

SunilKhanna  
11-02-2011 04:35 AM

[Re: Understanding the differences between the Cisco password \ secret](#)

RAHCDPBC  
10-03-2024 01:52 PM

[Configuring & Understanding OSPF HMAC Authentication](#)

Tim Glen  
10-10-2021 11:33 AM

[Understanding OSPF](#)

DrakoNoo  
02-27-2024 01:41 PM

First, who are we (what is our Router ID)?

```
r120#show ip ospf data
```

```
OSPF Router with ID (10.0.0.120) (Process ID 1)
```

Next, who are the other routers in our area?

```
Router Link States (Area 1)
```

Link ID	ADV Router	Age	Seq#	Checksum	Link count
10.0.0.111	10.0.0.111	600	0x8000023A	0x0092B3	1
10.0.0.112	10.0.0.112	1246	0x80000234	0x009CAC	1
10.0.0.113	10.0.0.113	148	0x8000022C	0x004399	3
10.0.0.120	10.0.0.120	152	0x80000240	0x0046CB	1

This tells us there are four routers in Area 1. The router with RID 10.0.0.113 has 3 links in Area 1, every one else has only 1 link.

Next, who are all of the DRs in this Area? What network segments do they represent?

```
Net Link States (Area 1)
```

Link ID	ADV Router	Age	Seq#	Checksum
192.168.1.112	10.0.0.112	1862	0x80000237	0x00D860
192.168.7.113	10.0.0.113	12	0x80000001	0x00E8F5

Routers 10.0.0.112 and 10.0.0.113 are the router IDs of the DRs for two segments. 192.168.1.112 and 192.168.7.113 represent the IP address of the DR on that segment. We will see later that if we were to look at the Router LSA for 10.0.0.112, for example, we would see 192.168.1.112 as one of the interfaces owned by that router.

The Summary Network LSAs (Type 3) are generated by the ABRs and will give us information about every segment in the network, outside of our Area. Type 1 and Type 2 LSAs are not flooded beyond an ABR. The ABR is responsible for taking all of the information in Type 1 and Type 2 LSAs and repackaging them into Type 3 LSAs.

```
Summary Net Link States (Area 1)
```

Link ID	ADV Router	Age	Seq#	Checksum
10.0.0.119	10.0.0.111	1215	0x8000022A	0x00A845
10.0.0.119	10.0.0.112	1862	0x80000229	0x00A449
192.168.0.0	10.0.0.111	1215	0x80000234	0x00D842
192.168.0.0	10.0.0.112	1862	0x80000233	0x00D446
192.168.2.0	10.0.0.111	1215	0x80000234	0x0027E7
192.168.2.0	10.0.0.112	1862	0x80000233	0x0023EB
192.168.3.0	10.0.0.111	1215	0x80000232	0x008481
192.168.3.0	10.0.0.112	1862	0x80000232	0x007E86
192.168.4.0	10.0.0.111	1215	0x80000232	0x00798B
192.168.4.0	10.0.0.112	1862	0x80000232	0x007390
192.168.5.0	10.0.0.111	1215	0x80000232	0x006E95
192.168.5.0	10.0.0.112	1862	0x80000232	0x00689A
192.168.6.0	10.0.0.111	1215	0x80000231	0x00C930
192.168.6.0	10.0.0.112	1862	0x80000231	0x00C335

From this we know Area 1 has two ABRs with RIDs 10.0.0.111 and 10.0.0.112. We also see a total of 7 segments in the entire OSPF network. Each network is seen twice because each ABR generates its own LSA. Two ABRs means two LSAs.

Type 4, Summary Network LSAs are next. These are generated by the ABRs (10.0.0.111 and 10.0.0.112) to represent any routers or ABRs outside of our Area that is passing along Type 5 (external LSAs). This may be a little confusing at this point but it will make more sense when we start working through the topology.


```
Summary ASB Link States (Area 1)
```

Link ID	ADV Router	Age	Seq#	Checksum
10.0.0.114	10.0.0.111	1215	0x80000232	0x00E915
10.0.0.114	10.0.0.112	1862	0x80000232	0x00E31A

Finally the external routes are represented by Type 5 LSAs.


```
Type-5 AS External Link States
```

Link ID	ADV Router	Age	Seq#	Checksum	Tag
172.16.0.113	10.0.0.113	631	0x80000001	0x00F006	0




Here we see two different prefixes being redistributed into OSPF. The ADV Router is either the configured with the redistribute command (10.0.0.113) or an ABR connected to a NSSA area where redistribution is happening.


With this information let's build some high level topologies. First, start with what we know from the Type 1 LSAs (all the routers in our area)




We will skip the Type 2 Network LSAs for now and go to the Type 3 Summary Network LSAs. This gives us the other subnets in the network and the ABRs for Area 1



The Type 4 ASBR Summary LSAs let us know that 10.0.0.114 is also an ABR on Area 0



and finally, the Type 5's tell us about the externals. Using the "ADV Router" field we can figure out where those routes come from.



Just from looking at the summary information in the database we've been able to put a lot of information together. Now we can start looking into the LSAs to get an idea of what the connectivity of Area 1 looks like.

We will start with router **r120**. Since we don't know anything about the links **r120** has, we start with a router with no connections.



To see the connections on **r120** we'll need to look at the Router LSA that is generated by r120 (remember: Router LSAs are represented by the Router ID)

```
r120#show ip ospf database router 10.0.0.120

OSPF Router with ID (10.0.0.120) (Process ID 1)

Router Link States (Area 1)

LS age: 408

Options: (No TOS-capability, DC)
```

LS Type: Router Links

Link State ID: 10.0.0.120

Advertising Router: 10.0.0.120

LS Seq Number: 8000023C

Checksum: 0x815

Length: 36

Number of Links: 1

Link connected to: a Transit Network

(Link ID) Designated Router address: 192.168.7.113

(Link Data) Router Interface address: 192.168.7.120

Number of MTID metrics: 0

TOS 0 Metrics: 10

From this we know a few things:

- 1.) There is a single interface with IP 192.168.7.120
- 2.) There is at least one other router on this segment with IP 192.168.7.113, and this is the DR
- 2a.) Because there is a DR, we know this interface is multi-access (not point-to-point)
- 3.) The Router ID (10.0.0.120) is not advertised in OSPF (because there is no link information representing the router ID)
- 4.) The metric we are advertising is 10

We have an IP and a DR, but we don't know the subnet mask or which router in Area 1 owns the DR IP address. There is where the **Type 2** LSA comes in. Remember the Type 2 is generated by the DR for a segment, and represents that segment, so we look for the segment DR.

```
r120#show ip ospf data network 192.168.7.113

      OSPF Router with ID (10.0.0.120) (Process ID 1)

          Net Link States (Area 1)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 93

Options: (No TOS-capability, DC)

LS Type: Network Links

Link State ID: 192.168.7.113 (address of Designated Router)

Advertising Router: 10.0.0.113

LS Seq Number: 80000004

Checksum: 0xE2F8


Length: 32

Network Mask: /24

      Attached Router: 10.0.0.113

      Attached Router: 10.0.0.120
```

A lot of great information here. First, we see the advertising router, which is the Router ID of the DR. In this case it's 10.0.0.113. Now we know who **r120** is attached to. We also see the network mask (/24) and all of the routers on the segment. In this case only r120 and 10.0.0.113 are on the segment. If there were other routers on this segment we would see their Router IDs in the "Attached Router" list. So let's update the topology diagram.



Now we can look at the **Router LSA** of 10.0.0.113

```
r120#show ip ospf data router 10.0.0.113
```

Router Link States (Area 1)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 395

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.113

Advertising Router: 10.0.0.113

LS Seq Number: 80000256

Checksum: 0x5465

Length: 60

AS Boundary Router

Number of Links: 3

Link connected to: a Stub Network

(Link ID) Network/subnet number: 10.0.0.113

(Link Data) Network Mask: 255.255.255.255

Number of MTID metrics: 0

TOS 0 Metrics: 1

Link connected to: a Transit Network

(Link ID) Designated Router address: 192.168.7.113

(Link Data) Router Interface address: 192.168.7.113

Number of MTID metrics: 0

TOS 0 Metrics: 10

Link connected to: a Transit Network

(Link ID) Designated Router address: 192.168.1.112

(Link Data) Router Interface address: 192.168.1.113

Number of MTID metrics: 0

TOS 0 Metrics: 10

Here we see three interfaces: 10.0.0.113, 192.168.7.113 and 192.168.1.113. We see that 10.0.0.113 is a "**Stub Network**". This does not have any relationship to a **Stub Area**, a "stub network" is simply an interface with no OSPF neighbors on it. We can also see that we are not the DR on the segment for 192.168.1.113. Let's take a look at the **Type 2** for that segment. Remember, the Type 2 is represented by the DR for that segment.

r120#show ip ospf data network 192.168.1.112

Net Link States (Area 1)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 161

Options: (No TOS-capability, DC)

LS Type: Network Links

Link State ID: 192.168.1.112 (address of Designated Router)

Advertising Router: 10.0.0.112

LS Seq Number: 80000261

Checksum: 0x848A

Length: 36

Network Mask: /24

Attached Router: 10.0.0.112

Attached Router: 10.0.0.111

Attached Router: 10.0.0.113

We know that routers 10.0.0.112, 10.0.0.111 and 10.0.0.113 are all attached to this segment. Now we can look at the **Router LSAs** for routers 10.0.0.112 and 10.0.0.111. This will provide us with their interface IPs as well as any Stub Networks we haven't seen yet.

```
r120#show ip ospf data router 10.0.0.111

      OSPF Router with ID (10.0.0.120) (Process ID 1)

          Router Link States (Area 1)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 1004

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.111

Advertising Router: 10.0.0.111

LS Seq Number: 80000264

Checksum: 0x3EDD

Length: 36

Area Border Router

Number of Links: 1

  Link connected to: a Transit Network

    (Link ID) Designated Router address: 192.168.1.112

    (Link Data) Router Interface address: 192.168.1.111

    Number of MTID metrics: 0

    TOS 0 Metrics: 10
```

```
r120#show ip ospf data router 10.0.0.112

      OSPF Router with ID (10.0.0.120) (Process ID 1)

          Router Link States (Area 1)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 1444

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.112

Advertising Router: 10.0.0.112

LS Seq Number: 8000025E

Checksum: 0x48D6

Length: 36

Area Border Router

Number of Links: 1

  Link connected to: a Transit Network

    (Link ID) Designated Router address: 192.168.1.112


    (Link Data) Router Interface address: 192.168.1.112

    Number of MTID metrics: 0

    TOS 0 Metrics: 10
```

Now we know that the DR, 192.168.1.112, is router 10.0.0.112. We know that router 10.0.0.111 is also connected to the 192.168.1.0/24 segment with IP 192.168.1.111. We now know the entire topology for Area 1.





We know everything there is to know about Area 1. There is nothing to learn from router 10.0.0.113, since all of the links on that router are discovered. The next point to continue mapping the network would be on one of the ABRs. We will start with 10.0.0.112, or **r112**. Since r112 is an ABR it will have Type 1, 2, 3 and 4 information for both Area 1 and Area 0. We will want to focus on the Area 0 information. Let's get started by looking at our own Router LSA

```
OSPF Router with ID (10.0.0.112) (Process ID 1)
```

```
Router Link States (Area 0)
```

```
LS age: 720
```

```
Options: (No TOS-capability, DC)
```

```
LS Type: Router Links
```

```
Link State ID: 10.0.0.112
```

```
Advertising Router: 10.0.0.112
```

```
LS Seq Number: 80000262
```

```
Checksum: 0x20FD
```

```
Length: 36
```

```
Area Border Router
```

```
Number of Links: 1
```

```
Link connected to: a Transit Network
```

```
(Link ID) Designated Router address: 192.168.0.111
```

```
(Link Data) Router Interface address: 192.168.0.112
```

```
Number of MTID metrics: 0
```

```
TOS 0 Metrics: 10
```

Looks like we only have link 192.168.0.112 in this area, and we are not the DR on this segment. Now we take a look at the Type 2 LSA for this segment.

```
r112#show ip ospf data network 192.168.0.111
```

```
OSPF Router with ID (10.0.0.112) (Process ID 1)
```

```
Net Link States (Area 0)
```

```
Routing Bit Set on this LSA in topology Base with MTID 0
```

```
LS age: 388
```

```
Options: (No TOS-capability, DC)
```

```
LS Type: Network Links
```

```
Link State ID: 192.168.0.111 (address of Designated Router)
```

```
Advertising Router: 10.0.0.111
```

```
LS Seq Number: 80000261
```

```
Checksum: 0x759F
```

```
Length: 36
```

```
Network Mask: /24
```

```
Attached Router: 10.0.0.111
```

```
Attached Router: 10.0.0.110
```

```
Attached Router: 10.0.0.112
```

We see that the advertising router represents the Router ID of the DR, or 10.0.0.111, who we already know is the other ABR for Area 1. We also see that there is a third router on this segment with Router ID 10.0.0.110. Let's get the interface information from 10.0.0.111

```
r112#show ip ospf data router 10.0.0.111

      OSPF Router with ID (10.0.0.112) (Process ID 1)

      Router Link States (Area 0)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 700

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.111

Advertising Router: 10.0.0.111

LS Seq Number: 80000268

Checksum: 0x1605

Length: 36

Area Border Router

Number of Links: 1

  Link connected to: a Transit Network

    (Link ID) Designated Router address: 192.168.0.111

    (Link Data) Router Interface address: 192.168.0.111

    Number of MTID metrics: 0

      TOS 0 Metrics: 10
```

One interface here, with IP 192.168.0.111. This is the same segment as **r112** and Router 10.0.0.110. Finally, let's look at 10.0.0.110

```
r112#show ip ospf data router 10.0.0.110

      OSPF Router with ID (10.0.0.112) (Process ID 1)

      Router Link States (Area 0)

LS age: 1232

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.110

Advertising Router: 10.0.0.110

LS Seq Number: 80000263

Checksum: 0x4E09

Length: 48

Number of Links: 2

  Link connected to: a Transit Network

    (Link ID) Designated Router address: 192.168.0.111

    (Link Data) Router Interface address: 192.168.0.110

    Number of MTID metrics: 0

      TOS 0 Metrics: 10

  Link connected to: a Transit Network

    (Link ID) Designated Router address: 192.168.2.110


    (Link Data) Router Interface address: 192.168.2.110

    Number of MTID metrics: 0

      TOS 0 Metrics: 10
```

We see that 10.0.0.110 owns the IP 192.168.0.110. We also see a second interface, 192.168.2.110. On this second segment 10.0.0.110 is the DR. Let's up the topology diagram for Area 0:





Let's keep moving down. First, we look at the Type 2 from 192.168.2.110, then we'll look at the Type 1 LSAs from the other routers on this segment.

```
r112#show ip ospf data net 192.168.2.110

      OSPF Router with ID (10.0.0.112) (Process ID 1)

          Net Link States (Area 0)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 781

Options: (No TOS-capability, DC)

LS Type: Network Links

Link State ID: 192.168.2.110 (address of Designated Router)

Advertising Router: 10.0.0.110

LS Seq Number: 80000261

Checksum: 0x1779

Length: 32

Network Mask: /24

    Attached Router: 10.0.0.110

    Attached Router: 10.0.0.114
```

And now the Type 1 for 10.0.0.114

```
r112#show ip ospf data router 10.0.0.114

      OSPF Router with ID (10.0.0.112) (Process ID 1)

          Router Link States (Area 0)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 889

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.114

Advertising Router: 10.0.0.114

LS Seq Number: 80000265

Checksum: 0x1178

Length: 48

Area Border Router

AS Boundary Router

Number of Links: 2

    Link connected to: a Stub Network

        (Link ID) Network/subnet number: 192.168.3.0

        (Link Data) Network Mask: 255.255.255.0

        Number of MTID metrics: 0

        TOS 0 Metrics: 10

    Link connected to: a Transit Network
```

(Link ID) Designated Router address: 192.168.2.110

(Link Data) Router Interface address: 192.168.2.114

Number of MTID metrics: 0

TOS 0 Metrics: 10


We have two links again, one connected to the segment with 10.0.0.110 and a new segment. Again, notice that the segment 192.168.3.0 is a *Stub Network*, so there are no other OSPF speakers on this link. Now, before we think we've finished up, we haven't looked at the **Type 3** LSAs that are generated by ABRs. We don't know if there is another ABR in Area 0, so let's look

Summary Net Link States (Area 0)

Link ID	ADV Router	Age	Seq#	Checksum
10.0.0.113	10.0.0.111	397	0x80000264	0x004394
10.0.0.113	10.0.0.112	17	0x80000264	0x003D99
10.0.0.119	10.0.0.114	1276	0x80000258	0x00715F
192.168.1.0	10.0.0.111	397	0x80000263	0x006F7B
192.168.1.0	10.0.0.112	792	0x80000262	0x006B7F
192.168.4.0	10.0.0.114	1036	0x80000261	0x0040A6
192.168.5.0	10.0.0.114	1036	0x80000261	0x0035B0
192.168.6.0	10.0.0.114	1036	0x80000260	0x00904B
192.168.7.0	10.0.0.111	397	0x80000265	0x008D4B
192.168.7.0	10.0.0.112	17	0x80000265	0x008750

Before addressing the new routes here, you can see the Type 3 LSAs in Area 0 that are generated by the two ABRs, 10.0.0.111 and 10.0.0.112. These routes here are all of the routes in Area 1, that we just described. This is how an ABR hides the details of an Area from the rest of the network.

We see four new networks all coming from the ABR 10.0.0.114. Now we can update our topology diagram of Area 0.



Again, we need to jump to our ABR to see what's going on in the rest of the network.

On **r114** things get interesting. Looking at the LSAs we see that **r114** is in 3 areas.

```
r114# show ip ospf data | i States
Router Link States (Area 0)
Net Link States (Area 0)
Summary Net Link States (Area 0)
Summary ASB Link States (Area 0)
Router Link States (Area 2)
Net Link States (Area 2)
Summary Net Link States (Area 2)
Router Link States (Area 3)
Net Link States (Area 3)
Summary Net Link States (Area 3)
Type-7 AS External Link States (Area 3)
Type-5 AS External Link States
```

But things look a little fishy in Area 2 and Area 3. Notice that Area 2 has no "Summary ASB Link States" (Type 4). Also notice that Area 3 has "Type-7 AS External Link States".

Let's start with Area 2.

If we are in an area that does not have any Type 4 LSAs, that area can not have external routes. OSPF works by linking the information carried in a Type-4 LSA to the information carried in the Type-5 LSA to build a tree. OSPF Stub areas do not allow any external information, matching this description. We can assume that Area 2 is a **Stub Area**.

Again, let's get a lay of the land by looking at the Router LSA summaries.

```
Router Link States (Area 2)

Link ID      ADV Router    Age      Seq#          Checksum Link count
10.0.0.114   10.0.0.114    23       0x8000026C   0x00B250 1
10.0.0.115   10.0.0.115    1584     0x80000269   0x00B350 1
10.0.0.116   10.0.0.116    745      0x8000026E   0x00F225 2
10.0.0.119   10.0.0.119    706      0x8000026B   0x0074E7 2
```

We can see there are four routers in the area. 10.0.0.116 and 10.0.0.119 both have two links.

Now let's look at our Router LSA

```
r114#show ip ospf data router 10.0.0.114
```

```
Router Link States (Area 2)

LS age: 1234

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.114

Advertising Router: 10.0.0.114

LS Seq Number: 80000265

Checksum: 0xC049

Length: 36

Area Border Router

Number of Links: 1

Link connected to: a Transit Network

(Link ID) Designated Router address: 192.168.5.114

(Link Data) Router Interface address: 192.168.5.114

Number of MTID metrics: 0

TOS 0 Metrics: 10
```

Now the Type-2, Network LSA

```
r114#show ip ospf data net 192.168.5.114
```

```
OSPF Router with ID (10.0.0.114) (Process ID 1)

Net Link States (Area 2)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 1312

Options: (No TOS-capability, DC)

LS Type: Network Links

Link State ID: 192.168.5.114 (address of Designated Router)

Advertising Router: 10.0.0.114

LS Seq Number: 80000263

Checksum: 0xD429

Length: 36

Network Mask: /24

Attached Router: 10.0.0.114

Attached Router: 10.0.0.115
```

Next, the Router LSA (Type-1) of our **Attached Routers**

```
r114#show ip ospf data router 10.0.0.115

      OSPF Router with ID (10.0.0.114) (Process ID 1)

      Router Link States (Area 2)

LS age: 1000

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.115

Advertising Router: 10.0.0.115

LS Seq Number: 80000263

Checksum: 0xBF4A

Length: 36

Number of Links: 1

  Link connected to: a Transit Network

    (Link ID) Designated Router address: 192.168.5.114

    (Link Data) Router Interface address: 192.168.5.115

      Number of MTID metrics: 0

      TOS 0 Metrics: 10
```

```
r114#show ip ospf data router 10.0.0.116

      OSPF Router with ID (10.0.0.114) (Process ID 1)

      Router Link States (Area 2)

LS age: 269

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.116

Advertising Router: 10.0.0.116

LS Seq Number: 80000268

Checksum: 0xFE1F

Length: 48

Number of Links: 2

  Link connected to: a Transit Network

    (Link ID) Designated Router address: 192.168.5.114

    (Link Data) Router Interface address: 192.168.5.116

      Number of MTID metrics: 0

      TOS 0 Metrics: 10

  Link connected to: a Transit Network


    (Link ID) Designated Router address: 192.168.6.119

    (Link Data) Router Interface address: 192.168.6.116

      Number of MTID metrics: 0

      TOS 0 Metrics: 10
```

Let's digest this here. First 10.0.0.115 has a single interface with IP 192.168.5.115. Next we see 10.0.0.116 with two interfaces, 192.168.5.116 and 192.168.6.116. Let's update the topology and then take a look at the segment with DR 192.168.6.119. This must be the router 10.0.0.119, the only router in Area 2 we haven't looked at yet.



Remember that routers 10.0.0.116 and 10.0.0.119 both had two links. We have discovered the two links on 10.0.0.116, but we still have one link on 10.0.0.119 to find, so let's look at the Type-1 for 10.0.0.119

```
r114#show ip ospf data router 10.0.0.119

      OSPF Router with ID (10.0.0.114) (Process ID 1)

      Router Link States (Area 2)

LS age: 1272
Options: (No TOS-capability, DC)
LS Type: Router Links
Link State ID: 10.0.0.119
Advertising Router: 10.0.0.119
LS Seq Number: 8000026B
Checksum: 0x74E7
Length: 48
Number of Links: 2

  Link connected to: a Stub Network

    (Link ID) Network/subnet number: 10.0.0.119

    (Link Data) Network Mask: 255.255.255.255

    Number of MTID metrics: 0

    TOS 0 Metrics: 1

  Link connected to: a Transit Network


    (Link ID) Designated Router address: 192.168.6.119

    (Link Data) Router Interface address: 192.168.6.119

    Number of MTID metrics: 0

    TOS 0 Metrics: 10
```

Now we have discovered all of the links in Area 2. Because Area 2 still receives Type-3 LSAs, it will know about all of the links in the OSPF network. The only thing it will not have will be the external routes that are injected into OSPF.



Remember that **r114** was in three Areas: Area 0, Areas 2 and Area 3. Before digging into Area 3, let's take another look at the LSAs that exist in Area 3.

```
r114#show ip ospf data | i Area 3

Router Link States (Area 3)

Net Link States (Area 3)

Summary Net Link States (Area 3)

Type-7 AS External Link States (Area 3)
```

We see Type 1 (Router Link States), Type 2 (Net Link State), Type 3 (Summary Net Link) and Type 7 (Type-7 AS External). Similar to Area 2, we do not see Type 4 or Type 5 LSAs. However we see Type-7 LSAs, which only exist in **Not So Stubby Areas** (NSSA). In a normal Stub area external route information is not allowed. NSSA areas allow us to have all of the features of a Stub area (no externals from other parts of the network) while still allowing external information to be originated in this area. To accomplish this, NSSA areas do not allow Type-5 (normal external LSAs) and use a special Type-7 LSAs. When the Type-7 arrives on the ABR (**r114** in this case), the ABR must convert this Type-7 to a Type-5 for the rest of the network. We'll take a look at this process in a little while.

First, let's see how many routers and links are in Area 3

```
Router Link States (Area 3)

Link ID      ADV Router    Age      Seq#          Checksum Link count
10.0.0.114   10.0.0.114    1610    0x80000335   0x00B37A  1
10.0.0.117   10.0.0.117    1344    0x80000333   0x00A881  1
10.0.0.118   10.0.0.118    802     0x80000332   0x00AE77  1
```

We have 3 routers, each with 1 link. Now, as always, take a look at our Type-1

```
r114#show ip ospf data router 10.0.0.114

Router Link States (Area 3)

LS age: 723

Options: (No TOS-capability, DC)

LS Type: Router Links

Link State ID: 10.0.0.114

Advertising Router: 10.0.0.114

LS Seq Number: 80000334

Checksum: 0xB579

Length: 36

Area Border Router

AS Boundary Router

Number of Links: 1

Link connected to: a Transit Network

(Link ID) Designated Router address: 192.168.4.117

(Link Data) Router Interface address: 192.168.4.114

Number of MTID metrics: 0

TOS 0 Metrics: 10
```

A single link with IP 192.168.4.114 and DR 192.168.4.117. Now the Type-2

```
r114#show ip ospf data net 192.168.4.117

OSPF Router with ID (10.0.0.114) (Process ID 1)

Net Link States (Area 3)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 635

Options: (No TOS-capability, DC)

LS Type: Network Links

Link State ID: 192.168.4.117 (address of Designated Router)

Advertising Router: 10.0.0.117

LS Seq Number: 80000330

Checksum: 0xCE50
```

Length: 36

Network Mask: /24

Attached Router: 10.0.0.117

Attached Router: 10.0.0.114

Attached Router: 10.0.0.118

Here are three routers attached to this segment. **r114**, the DR and a third router. Now the Type-1 LSAs for the other routers.

```
r114#show ip ospf data router 10.0.0.117
```

```
    OSPF Router with ID (10.0.0.114) (Process ID 1)
```

```
        Router Link States (Area 3)
```

```
LS age: 794
```

```
Options: (No TOS-capability, DC)
```

```
LS Type: Router Links
```

```
Link State ID: 10.0.0.117
```

```
Advertising Router: 10.0.0.117
```

```
LS Seq Number: 80000333
```

```
Checksum: 0xA881
```

```
Length: 36
```

```
Number of Links: 1
```

```
  Link connected to: a Transit Network
```

```
    (Link ID) Designated Router address: 192.168.4.117
```

```
    (Link Data) Router Interface address: 192.168.4.117
```

```
    Number of MTID metrics: 0
```

```
    TOS 0 Metrics: 10
```

```
r114#show ip ospf data router 10.0.0.118
```

```
    OSPF Router with ID (10.0.0.114) (Process ID 1)
```

```
        Router Link States (Area 3)
```

```
Routing Bit Set on this LSA in topology Base with MTID 0
```

```
LS age: 257
```

```
Options: (No TOS-capability, DC)
```

```
LS Type: Router Links
```

```
Link State ID: 10.0.0.118
```

```
Advertising Router: 10.0.0.118
```

```
LS Seq Number: 80000332
```

```
Checksum: 0xAE77
```

```
Length: 36
```

```
AS Boundary Router
```

```
Number of Links: 1
```

```
  Link connected to: a Transit Network
```

```
    (Link ID) Designated Router address: 192.168.4.117
```

```
    (Link Data) Router Interface address: 192.168.4.118
```

```
    Number of MTID metrics: 0
```


```
    TOS 0 Metrics: 10
```

We see IPs 192.168.4.118 and 192.168.4.117. Here's the topology for Area 3.



Router Link States (Area 3)

Link ID	ADV Router	Link count
10.0.0.114	10.0.0.114	1
10.0.0.117	10.0.0.117	1
10.0.0.118	10.0.0.118	1



But let's not forget about the Type-7 LSAs we saw earlier. Because these are Type-7, we are not looking at *external* LSAs but *nssa-external* LSAs

```
r114#show ip ospf data nssa-external

      OSPF Router with ID (10.0.0.114) (Process ID 1)

      Type-7 AS External Link States (Area 3)

Routing Bit Set on this LSA in topology Base with MTID 0

LS age: 952

Options: (No TOS-capability, Type 7/5 translation, DC)

LS Type: AS External Link

Link State ID: 172.16.0.118 (External Network Number )

Advertising Router: 10.0.0.118

LS Seq Number: 800000FF

Checksum: 0xEC13

Length: 36

Network Mask: /32

      Metric Type: 2 (Larger than any link state path)

      MTID: 0

      Metric: 20

      Forward Address: 192.168.4.118

      External Route Tag: 0
```

This is the LSA representing the external network 172.16.0.118/32. Within this area the routers should send traffic for this destination to the Forwarding Address of 192.168.4.118. Once the LSA arrives on the ABR, **r114**, it will be converted into a Type-5 LSA and sent to all other areas (that aren't stubs, meaning that Area 2 will not see this LSA). We can confirm this by looking at the Type-5 LSAs

```
r114#show ip ospf data external 172.16.0.118

      OSPF Router with ID (10.0.0.114) (Process ID 1)

      Type-5 AS External Link States

LS age: 146

Options: (No TOS-capability, DC)

LS Type: AS External Link

Link State ID: 172.16.0.118 (External Network Number )

Advertising Router: 10.0.0.114

LS Seq Number: 80000101

Checksum: 0x9477

Length: 36

Network Mask: /32

      Metric Type: 2 (Larger than any link state path)

      MTID: 0


      Metric: 20

      Forward Address: 192.168.4.118


      External Route Tag: 0
```

Here we see the Type-5 originated not by 10.0.0.118, like the Type-7, but by 10.0.0.114. This is due to the Type-7 to Type-5 conversion. Since **r114** is generating a new LSA it sets itself as the Advertising Router. You'll also notice that the *Forwarding Address* has remained the same. When other routers in the network build the tree to reach this external destination they will build to the best ABR to reach this network (since it would be part of a Type-3 LSA). For more information on Forwarding Addresses, there is a [great doc](#) on Cisco.com.

With all of this information we can finish the topology for Area 3



and then for the entire OSPF network.



## Summary

Hopefully reading the OSPF topology is a little more clear now. The less obvious takeaways are how OSPF scales by hiding topology information. You noticed that in an area we have a large number of Type 1 and Type 2 LSAs. Outside of that area there is only a single Type-3 LSA generated by each ABR. We can also use **Stub Areas** to hide external information, keeping even less information in the LSDB of the routers in those areas.

Finally, think about how each LSA type links together. OSPF's SPF algorithm links different pieces of information together. For a router in Area 1 to reach the external route in Area 3, it has to look at the Type-5 that represents the external route. Then it has to look at the Type-4 representing the ABR on the area that the ASBR lives in. Then we have to look at the Type-3 to get to that remote ABR. Finally we look at the Type-1 and Type-2 LSAs in our area to determine how to get to our closest ABR.

Each LSA serves a specific purpose and they all fit together to supply end-to-end connectivity.

Routing Protocols

ccie igp ospf route routing

323 Helpful

## Comments

jeffin4455 Level 1 08-14-2013 01:19 PM

Awesome!!!!  
 On how to make sense of the radom chatoic ospf database and build the network topology just by intreperting the sh ip odpf db command.  
 LSAs in live action here!!



Mark Schwartz Level 1

09-01-2013 12:00 PM

Outstanding!! Simply the best discussion on this subject I have seen.



danish.saeed Level 1

11-10-2013 09:20 AM

Excellent document.



sunishgandhi **Community Member**

12-24-2013 02:24 AM

Simply Awesome..!!

Prior reading this doc I used to get confused while reading ospf database to build topologies but this doc clears all my doubts and now I can build topologies very easily without any doubts..



CHAD REID Level 1

12-24-2013 07:01 AM

This document really brought a lot of the pieces together for OSPF. I've studied the LSAs and know how to spout off canned answers about what an LSA means, but this document actually gave me knowledge on interpreting the LSAs and building the trees.



aadil.bhatia **Community Member**

01-02-2014 10:18 AM

Too Good !!! Cleared so many of the concepts...  
Thanks for the post...



kenxinjie **Community Member**

01-08-2014 10:50 PM

Very Good!

Only one doubt about the this last sentence at the paper , " Then we have to look at the Type-3 to get to that remote ABR. "  
I remember that the Type-3 LSA's ABR means the local ABR.



eng.amr84 Level 1

01-28-2014 10:38 AM

very useful



Rolando Valenzuela Level 4

02-11-2014 04:19 PM

Just awesome!!!!!!!!!!!!!!



Antonio Torres **Community Member**

02-27-2014 07:43 PM

thank you it did help me get thru my lab.....GREAT



cschmidt Community Member

08-04-2014 03:29 PM

I agree with the poster with this statement. Type 3 LSAs is what allows one router to obtain "O IA" routes. Type 3 LSA's allow a remote ABR to tell about the networks in one area and bring them into another area.



dmaillard91 Level 1

08-21-2014 08:18 AM

awesome post. Now OSPF is clear !!



ckyony001 Community Member

09-10-2014 02:44 AM

Excellent post. Highly recommended if you were like me fearful of the output of **ip ospf database** command



ivanov.arseniy Level 1

10-21-2014 04:58 AM

Thank you for this great post. One question -  
"Type 4, Summary Network LSAs are next"  
Did you mean ASBR Summary LSA? Although it in fact is network summary LSA, calling Type4 LSA a Summary Network LSA (without referencing ASBR) may bring some confusion.



Cenk Ali Mete Community Member

11-16-2014 02:00 PM

OSPF State is FULL  
Really Amazing Explanation!..

↑ Top

Quick Links

Contacts

Resources and Legal

- Community Feedback
- Help
- Terms & Conditions
- Privacy Statement
- Cookie Policy
- Trademarks
- Site Map
- Report Illegal Content